




LOWRANCE


SIMRAD

AUTO-STBY button INSTALLATION GUIDE

Dimensions



Mounting



Wiring diagram

Point-1 / RC42N

Note: The connection is color independent

